

EXTERNAL RECEIVER (KNL 138)

INSTRUCTION MANUAL

Thank you for purchasing KNL138 external receiver. It is compact, simple to operate and highly reliable.

(1) Wire Connection


Please connect the wires by following instructions:

(a) Connect the BLACK wire and BROWN wire from the External Receiver (KNL138) into the O/S/C terminals which are for PUSH BUTTON.

NOTE: The BLACK wire MUST be connected to the O/S/C terminal which is near the edge side.

(b) Connect the third RED wire into the COM terminal.

Please refer to the following illustration of cable connection:



(2) Program Receiver and Remote

Press and release the Learn Button in Receiver. The LED light is ON. Press the key in the Remote twice. The LED will blink quickly. Now the Receiver has learned the code.

Repeat the procedure if more Remotes are required to be programmed.

NOTE: The Receiver can learn up to 250 Remotes.

(3) Erase all Remote Codes

Press and release the Learn Button until the LED light is OFF. Now all Remote codes has been erased.